
Truphone SIM Setup

This document is a SIM card guide applicable to our DVKs – part numbers 453-00010-K1 and 453-00011-K1. The included Truphone SIM card is part number SIM-S-IO3-TRI-2-LP.


As of May 2020, Truphone only supports LTE M on this SIM card. There is no NB-IoT support. We will update this when Truphone expands support to NB-IoT. In the meantime, contact support@lairdconnect.com if you want to test with NB-IoT.

To set up your Truphone SIM, follow these steps:


- 1. Visit truphone.com/connectit.
- 2. Unless you already have an account, click **Sign up** located at the bottom of the LOG IN window.




- 3. Enter your contact information and a password.
- 4. Select your preferred account type (Personal or Business).
- 5. Click Get Started.




6. Enter the verification code that was sent to your email address.




7. Enter your profile information and click **Create account**.




8. Select Activate SIMS.



9. Enter the ICCID and PUK located on the SIM card



The following is what the screen should look like once you enter the ICCID.



Plan Selection: The Pinnacle 100 comes with a complimentary data bucket of 250 MB.

If you enter credit card details, your card will not be charged unless you choose to purchase additional data.

