

AT Interface – Pairing (vSP & non-vSP Mode)

BL65x smartBASIC modules

Application Note

v1.0

1 INTRODUCTION

The goal of this document is to demonstrate the use of the smartBASIC *AT.Interface.BL65x.sb* application to pair two devices (encrypt the connection between the devices) and enable MITM protection (if required), using a few simple AT commands and S-Register configurations. Once the devices have paired, the encryption keys will be stored in the Bonded Device Database for future connections.

2 OVERVIEW

AT Interface supports two modes of operation: **vSP** (Virtual Serial Port) Mode (default), which enables [Laird's custom Virtual Serial Port service](#) and **non-vSP** mode for setting up or connecting to other Bluetooth LE services. For more information on these two modes see section 3.1 of the [User Guide - BL65x AT Interface Application](#).

It is recommended that users reference the [User Guide - BL65x AT Interface Application](#) along with this user guide. All commands mentioned in this application note are fully defined in the [User Guide - BL65x AT Interface Application](#). **Section two of the User Guide also contains instructions for loading the AT.Interface.bl65x.sb smartBASIC application to the module.**

2.1 Contents

- [Requirements](#)
- [Preparation](#)
- [Set Up Central Role Device](#)
- [Set Up Peripheral Role Device](#)
- [vSP Pairing \(Encryption Only – no MITM\)](#)
- [non-vSP mode Pairing \(Encryption only No MITM\)](#)
- [vSP & non-vSP mode Pairing \(Encryption with MITM\)](#)
- [Checking Bonded Device Database Options](#)

3 REQUIREMENTS


- Two BL65x Development Kits (BL652, BL653, BL654, BL654PA), **or** two smartBASIC-BL654 dongles [451-00003]), each loaded with **\$autorun\$.AT.interface.BL65x.sb**. (v5.04 or later)
 - One to act as Central Role Device (GATT Client)
 - One to act as Peripheral Role Device (GATT Server)
- [UwTerminalX](#)
- [User Guide - BL65x AT Interface Application](#)

4 PREPARATION

This application note assumes you have already loaded the most current version of the at.interface.bl65x.sb sample application available from the [BL65x GitHub](#) repository to both the Central Role and Peripheral Role devices and are getting the OK response in UwTerminalX after pressing **Enter**. For instructions on how to load the application to the module please reference section 2 of [User Guide - BL65x AT Interface Application](#).

Connect both DVKs (or USB dongles) to the PC via the UART Interface and verify the COM ports. Connect each device to a separate instance of UwTerminalX. Press **Enter** to confirm the AT Interface application is running – you should receive an OK response. If you receive 00 as a response, the AT Interface application is not running; to run the AT Interface application enter \$autorun\$ and press **Enter**. Verify the version of the AT Interface application is 5.04 or later, and the AT Interface Library version is 4.05 or later using the following commands:

- `ATI 23` // Calls the version number of the AT Interface Application
- `ATI 33` // Calls the version number of the AT Interface Library



5 SET UP CENTRAL ROLE DEVICE


On the device acting in the Central role, send the following commands:

- `ati 0` // Calls device name
- `ati 3` // Calls smartBASIC firmware version
- `ati 4` // Calls the BT ADDR of the module
- `at+bndl` // Calls list of devices in the bonded device database
- `ats 100?` // Check Start-up Flags (see Figure 1)

Register	Description
100	Start-up Flags <ul style="list-style-type: none"> ▪ Bit 0: Set to VSPConnectable - hence populates GATT table and starts adverts ▪ Bit 1: Ignored if bit 0 is 1 otherwise start advertising with no timeout ▪ Bit 2: Ignored if bit 0 is 1 otherwise start scanning with no timeout ▪ Bit 3: Set for max bidirectional throughput of about 127kbps, otherwise half that. ▪ Bit 4: Use Data Length Extension (#define DLE_ATTRIBUTE_SIZE) in smartBASIC application ▪ Bit 5: Phy Rate <ul style="list-style-type: none"> 00 – 1MPHY 01 – Long Range – 125kbps 10 – RFU : will set 1 MPHY 11 – 2MPHY

Figure 1: Start up flags (S-Register 100)

Start-up flags by default have bits 0 and 3 set, which means the device will advertise for a vSP connection on startup/reset and will be configured for maximum bidirectional throughput, which only allows one connection.




6 SET UP PERIPHERAL ROLE DEVICE

On the Device acting in the Peripheral role, ensure the AT Interface application is loaded and running on the module by pressing **Enter** and looking for the **OK** response. Then send the following commands:

- `ATI 0` // Calls device name
- `ATI 3` // Calls the firmware version on the module
- `ATI 4` // Calls the BT ADDR of the module
- `AT+BNDL` // Calls list of devices in the bonded device database (EMPTY)
- `ATS 100?` // Check Start-up flags

Start-up flags by default have bits 0 and 3 set which means the device will advertise for a vSP connection on startup and is configured for Max bidirectional throughput.



7 VSP PAIRING (ENCRYPTION ONLY – NO MITM)

7.1 Step 1: Configure S Registers

In the AT Interface Application, S Register 102 is used to set the Encryption Requirement for incoming vSP connections. When set to 1, encryption is required for vSP connections. To configure the **Peripheral device** to require encrypted vSP Connections enter the following commands to set S Register 102 and save the changes:

Peripheral Role Device:

- `ATS 102=1` // Set S Register 102 to 1 to require encryption.
- `AT&W` // Save the S Register setting.
- `ATZ` // Soft Reset.
- `ATS 102?` // Verify new setting for S Reg 102.

```
UwTerminalX (v1.13a) Peripheral Role Device
Terminal Config Speed Test Update About Logs Editor
CTS DSR DCD RI RTS DTR BREAK LocalEcho LineMode Clear Close Port
[COM18:115200,N,8,1,H]{cr} Download Tx Left: 0 Tx: 733 Rx: 2557 Last Rx: 20/12 @ 12:22:25 Cancel

OK
ats 102 ? ← Check Default setting for S Reg 102 (0)
0
OK
ats 102=1 ← Set S Reg 102 to 1 to require Encryption for vSP Connections
OK
at&w ← Save S Reg Changes
OK
atz ← Soft Reset (required)
OK
ats 102? ← Verify new setting for S Reg 102
1
OK
[COM18:115200,N,8,1,H]{cr}
```

7.2 Step 2: Connect from Central Device

Enter the following commands to connect from the Central device:

- AT+LSCN 1 // Scan for 1 second (scan time can be adjusted)
- ATD [BTADDR-Peripheral] // Connect to Peripheral device in vSP mode

The image displays two screenshots of the UwTerminalX (v1.13a) application, illustrating the AT command sequence for connecting from a Central Role Device to a Peripheral Role Device.

Central Role Device Screenshot:

- The title bar indicates "Central Role Device".
- The terminal window shows the following commands and responses:
 - `ats 100 ?` returns `9`.
 - `OK` is received.
 - `at+lscn 1` is entered, with a callout "Scan for devices (1 Second)".
 - The response shows two discovered devices:
 - `AD1:0 01C7771F7CC04F -27 "LAIRD BL654-7CC04F"`
 - `AD1:3 0309C13B90E4CE -88 ""`
 - `OK` is received.
 - `atd 01C7771F7CC04F` is entered, with a callout "Connect to Peripheral device".
 - The response shows `ENCRYPT` and `CONNECT 0, 01C7771F7CC04F, 15000, 6000000, 0`, with a callout "Connection in Encrypted/Bonded and given connection handle of 0".
 - The response also includes `Hello from Central` and `Hello from Peripheral`.


Peripheral Role Device Screenshot:

- The title bar indicates "Peripheral Role Device".
- The terminal window shows the following commands and responses:
 - `ats 102 ?` returns `1`.
 - `OK` is received.
 - The response shows `RING 01C5D5833F7C96, T`, with a callout "Connection in Encrypted/Bonded and given connection handle of 0".
 - The response also includes `ENCRYPT` and `CONNECT 0, 01C5D5833F7C96, 15000, 6000000, 0`.
 - The response also includes `Hello from Central` and `Hello from Peripheral`.

Note: For an explanation of the connection response see section 3.4.1.1 of the [AT Interface User Guide](#). The number following "CONNECT" is the connection handle.

7.3 Step 3: Send Data over vSP Connection


The devices are now connected in vSP bridge mode with an encrypted connection and any data sent over the UART will be bridged via the vSP connection and sent to the connected device.



7.4 Step 4: Exit vSP Bridge Mode

To exit vSP bridge mode, complete the following:

- Disable LineMode in UwTerminalX on either Device.
- Send the escape characters ^^^^ with a 250ms delay between each character.
- The connection will terminate.



7.5 Check Bonded Device Database

Once the vSP connection is terminated, re-enable LineMode and then verify the devices are bonded by entering the command `AT+BNDL`

The image displays two screenshots of the UwTerminalX (v1.13a) application, illustrating the process of checking the bonded device database.

Top Screenshot: Central Role Device

- The window title is "Central Role Device".
- The terminal shows the command `at+lscn 1` and its output, including MAC addresses and a "Hello from Central" message.
- The command `at+bndl` is entered, and the response is highlighted in a yellow box: `capacity: 16, rolling: 1, persistent: 0` followed by a table of bonded devices.
- A yellow callout box points to the response, stating: "Response shows 1 rolling bond and lists MAC Address for Peripheral".

Bottom Screenshot: Peripheral Role Device


- The window title is "Peripheral Role Device".
- The terminal shows the command `ats 102 ?` and its output, including MAC addresses and a "Hello from Peripheral" message.
- The command `at+bndl` is entered, and the response is highlighted in a yellow box: `capacity: 16, rolling: 1, persistent: 0` followed by a table of bonded devices.
- A yellow callout box points to the response, stating: "Response shows 1 rolling bond and lists MAC Address for Central".

7.6 Reconnect in vSP Mode (Encrypted by default)

When reconnecting in vSP mode using the `ATD` command, after the devices have been paired & bonded, future connections will automatically be encrypted.

Central Role Device:

`ATD [BTADDR-Peripheral]`



Note: When encryption with MITM protection (ATS 102 =3) is required between two devices for vSP mode, it is necessary to initially use non-vSP mode to connect and pair the devices as explained in [9 vSP & non-vSP mode Pairing \(Encryption with MITM\)](#). Once the devices are paired, the encryption keys will be stored in the bonded device database, and subsequent connections whether in vSP mode or non-VSP mode will be encrypted.

8 NON-VSP MODE PAIRING (ENCRYPTION ONLY NO MITM)

8.1 Restore Default Settings and Clear Bonded Device Database

If the devices have been paired previously, it is recommended to restore the default settings and clear the Bonded Device Databases on BOTH devices using AT&F to restore default settings and AT+BNDX to clear the Bonded Device Database:


1. Break any existing vSP Bridge connection using the escape characters ^^^^ as explained in [7.4 Step 4: Exit vSP Bridge Mode](#) on either device.
2. Enter AT&F on each device to restore default settings.
3. Enter AT+BNDX to clear the bonded device database.
4. Verify the database has been cleared using AT+BNDL command.

Central Role Device

- AT&F // Reset Default Settings
- AT+BNDX // Clear Bonded Device Database
- AT+BNDL // Verify Database is empty

Peripheral Role Device

- AT&F // Reset Default Settings
- AT+BNDX // Clear Bonded Device Database
- AT+BNDL // Verify Database is empty



8.2 Configure Peripheral Device to use non-vSP Advert

On the Peripheral Role Device enter AT+LADV to start non-vSP adverts.

Peripheral Role Device

- AT+LADV //Start non-vSP Adverts

```
OK
at+bndx

OK
at+bndl

capacity: 16, rolling: 0, persistent: 0
OK
at+ladv
OK
```

Peripheral Role Device

Start non-vSP Adverts

8.3 Scan for Devices (Optional) & Connect:

On Central role device enter the following commands to scan (optional) for Peripheral devices and then connect:

Central Role Device:

- AT+LSCN 1 // Scan for 1 second (scan time can be adjusted)
- AT+LCON [BTADDR-Peripheral] // Connect in non-vSP mode to peripheral device

[COM14:115200,N,8,1,H]{cr} Download Tx Left: 0 | Tx: 470 | Rx: 1325 | Last Rx: 15/12 @ 15:57:29 |

```
at+bndl
capacity: 16, rolling: 0, persistent: 0
OK
at+lscn 1
AD1:0 01C7771F7CC04F -22 "LAIRD BL654-7CC04F"
AD1:0 01C7771F7CC04F -22 "LAIRD BL654-7CC04F"
AD1:0 01C7771F7CC04F -22 "LAIRD BL654-7CC04F"
OK
at+lcon 01C7771F7CC04F
connect 1, 01C7771F7CC04F, 15000, 6000000, 0
```

Central Role Device

Scan for 1 second

BTADDR-Peripheral

Connect to BTADDR-Peripheral

```
0
OK
RING 01C5D5833F7C96, U
CONNECT 0, 01C5D5833F7C96, 15000, 6000000, 0
```

Peripheral Role Device

Connection Made from Central

For an explanation of the connection response see section 3.4.1.1 of the [AT Interface User Guide](#). The number following "CONNECT" is the connection handle.

8.4 Pair and Bond Devices

Once connected send the `AT+PAIR[hIdx]` command to pair and bond with the connection handle returned in the connection response:

Central Role Device

- `AT+PAIR 1` // Pair with device – connection handle 1

```
[COM14:115200,N,8,1] Central Role Device 1648 Last Rx: 15/12
at+lecon 01c7771f7cc04f
connect 1, 01c7771f7cc04f, 15000, 6000000, 0
at+pair 1
OK
encrypt 1
PI:1, 0, 0, 5, 3

Peripheral Role Device
OK
connect 1, 01c5d5833f7c96, 15000, 6000000, 0
encrypt 1
PI:1, 0, 0, 5, 3
```

Note: For explanation of response to pairing see section 3.4.3.30 of the [AT Interface User Guide](#).

8.5 Read GATT Server Table Map

Confirm connection by reading GATT Server Table Map using `AT+GCTM [Hdlx]` command.

Central Role Device (GATT Client)

- `AT+GCTM 1` // Read GATT Svr

Table Map – Connection Handle 1

```
capa Central Role Device t: 0
0
OK
AT+GCTM 1
Read GATT Svr Table Map

TM:S:1, (9), FE011800
TM: C:3, 00000002, FE012A00, 0
TM: C:5, 00000002, FE012A01, 0
TM: C:7, 00000002, FE012A04, 0

TM: C:9, 00000002, FE012AA6, 0
TM:S:10, (13), FE011801

TM: C:12, 00000020, FE012A05, 0
TM: D:13, FE012902

TM:S:14, (65535), FD021101
TM: C:16, 00000010, FD022000, 0
TM: D:17, FE012902
TM: C:19, 0000000C, FD022001, 0

TM: C:21, 00000010, FD022002, 0
TM: D:22, FE012902
TM: C:24, 0000000C, FD022003, 0

OK
```

8.6 Check Bonded Device Databases on both devices

After Pairing check the Bonded Device Database using AT+BNDL command:

- AT+BNDL // Check Bonded Devices Database

```
encrypt 1
PI:1, 0, 0, 5, 3
at+bndl

capacity: 16, rolling: 1, persistent: 0
0 01C7771F7CC04F 001D0000
OK

encrypt 1
PI:1, 0, 0, 5, 3
at+bndl

capacity: 16, rolling: 1, persistent: 0
0 01C5D5833F7C96 001D0000
OK
```

8.7 Reconnect with Encryption – Non-vSP Mode

When reconnecting in non-vSP mode, even though the devices have been previously paired/bonded, the future connections will not automatically be encrypted. This is because characteristics can have different levels of security, therefore, to encrypt the connection using the stored keys it is necessary to send the AT+LENC hdIx command following the connection command as shown below:

Either Device

- AT+LDSC 1 // Disconnect from connection handle 1

Peripheral Role Device

- AT+LADV // Restart non-vSP Adverts

Central Role Device

- AT+LCON [BTADDR-Peripheral] // Reconnect with peripheral device
- AT+LENC 1 // Encrypt connection handle 1

```
encrypt 1
PI:1, 0, 0, 5, 3
at+ldsc 1

OK
discon 1, 22
at+lcon 01C7771F7CC04F

connect 1, 01C7771F7CC04F, 15000, 6000000, 0
at+lenc 1

encrypt 1

encrypt 1
PI:1, 0, 0, 5, 3
at+ladv

discon 1, 19
at+lcon 01C5D5833F7C96

connect 1, 01C5D5833F7C96, 15000, 6000000, 0
at+lenc 1

encrypt 1
```

9 VSP & NON-VSP MODE PAIRING (ENCRYPTION WITH MITM)

9.1 Restore Default Settings and Clear Bonded Device Database

If the devices have been paired previously, it is recommended you restore the default settings and clear the Bonded Device Databases on BOTH devices:

- AT+LDSC 1 // Disconnect from Handle 1 (from either Device)
- AT&F // Restore Default Settings (both devices)
- AT+BNDX // Clear Bonded Device Database (both devices)
- AT+BNDL // Verify Database is empty (both devices)

[COM14:115200,N,8,1,H]{cr} Central Role Device Rx: 2789 Last Rx: 20/1

```
discon 1, 19 ← Peripheral issued Disconnect Cmd
at&f ← Restore Default Settings
OK
at+bndx ← Clear Bonded Device Database
OK
at+bndl ← Verify Database is Empty
capacity: 16, rolling: 0, persistent: 0
OK
```

[COM18:115200,N,8,1,H]{cr} Peripheral Role Device Last Rx: 20/12

```
at+ldsc 1 ← Disconnect cmd issued
OK
discon 1, 22
at&f ← Restore Default Settings
OK
at+bndx ← Clear Bonded Device Database
OK
at+bndl ← Verify Database is Empty
capacity: 16, rolling: 0, persistent: 0
OK
```

9.2 Configure S Registers on Central Role Device


S Register 107 is used to set the I/O Capability used during the initial negotiation when pairing. This specifies the user interface that is available to expedite a pairing. 'Just Works' pairing implies there is no user interface therefore, the resulting encryption key will not be authenticated and so not immune to MITM (man-in-the-middle) attack. Valid values are as follows:

- 0 = Just Works
- 1 = Display with Y/N
- 2 = Keyboard only
- 3 = Display Only
- 4 = Keyboard + Display

For the purposes of this demonstration, we will be setting S Reg 107 on both devices to 4.

Central Role Device

- `ATS 107=4` // Configure S Reg 107 to 4
- `AT&W` // Save the changes
- `ATZ` // Soft Reset




9.3 Configure S Registers on Peripheral Role Device and start non-vSP Adverts

On the Peripheral Role Device, in addition to setting the I/O Cap setting via S Reg 107 to 4, we will also be setting the Encryption Requirements for vSP connections via S Reg 102 to 3, which will require both Encryption and MITM (Authentication) for incoming vSP Connections. This will have no impact on non-vSP connections; however, it will require making the initial vSP connection in non-vSP mode to allow for authentication to occur. After pairing/authenticating in non-vSP Modes subsequent vSP connections will meet these requirements.

Note: If you will not be using vSP mode, setting S Reg 102 is optional.

Peripheral Role Device

- `ATS 107=4` // Set S Reg 107 to 4
- `ATS 102=3` // Set S Reg 102 to 3 (Optional – Only required for vSP)
- `AT&W` // Save Settings
- `ATZ` // Soft Reset (required)
- `AT+LADV` // Start non-vSP Adverts



The screenshot shows a terminal window with the following text: `OK`, `at+bndl`, `capacity: 16, rolling: 0, persistent: 0`, `OK`, `ats 107=4`, `OK`, `ats 102=3`, `OK`, `at&w`, `OK`, `atz`, `OK`, `at+ladv`, `OK`. Annotations with yellow arrows point from text boxes to specific command lines: 'Peripheral Role Device' points to the first 'OK'; 'Set S Reg 107 to 4' points to 'ats 107=4'; 'Set S Reg 102 to 3' points to 'ats 102=3'; 'Save Settings' points to 'at&w'; 'Soft Reset (required)' points to 'atz'; and 'Start non-vSP Adverts' points to 'at+ladv'.

9.4 Connect, Pair & Authenticate Connection in non-vSP Mode

Issue the following commands to connect, pair and authenticate the connection.

Central Role Device:

- `AT+LCON [BTADDR-Peripheral]` // Initiate Connection
- `AT+PAIR 1` // Initiate Pairing connect handle 1
- `AT+PRSP 1,Y` // Respond to authentication comparecode request – connect handle 1

Peripheral Role Device:

- `AT+PRSP 1,Y` // Respond to authentication comparecode request

Connection is now encrypted and authenticated.

Enter `AT+GCTM [Hdlx]` on the Central Role device/GATT Client to read the GATT Table map of the Peripheral role device/GATT Server.

Central Role Device:

- `AT+GCTM 1` // Confirm connection by reading GATT Server

Table Map - Connection 1:

```
Central Role Device
at+lcon 01c7771f7cc04f ← Connect Devices
connect 1, 01c7771f7cc04f, 15000, 6000000, 0
at+pair 1 ← Pair and Bond Devices
OK
comparecode 1, 708599 ← Confirm codes on both devices match
at+prsp 1, Y ← Send Pair Response
OK
encrypt 1
PI:1, 0, 0, 5, F
at+gctm 1 ← Read GATT Table

TM:S:1, (9), FE011800
TM: C:3, 00000002, FE012A00, 0
TM: C:5, 00000002, FE012A01, 0

TM: C:7, 00000002, FE012A04, 0
TM: C:9, 00000002, FE012AA6, 0

TM:S:10, (13), FE011801
TM: C:12, 00000020, FE012A05, 0
TM: D:13, FE012902

TM:S:14, (65535), FD021101
TM: C:16, 00000010, FD022000, 0
TM: D:17, FE012902

TM: C:19, 0000000C, FD022001, 0
TM: C:21, 00000010, FD022002, 0
TM: D:22, FE012902
TM: C:24, 0000000C, FD022003, 0
OK
```

```
Peripheral Role Device
at+ladv ← Start non-vSP Adverts
OK
connect 1, 01c5d5833f7c96, 15000, 6000000, 0
comparecode 1, 708599 ← Confirm codes on both devices match
at+prsp 1,Y ← Send Pair Response
OK
encrypt 1 ← Connection is now Encrypted
PI:1, 0, 0, 5, F
```

9.5 Check Bonded Device Database on Both Devices

After pairing, check the bonded device database using AT+BNDL command:

- AT+BNDL // Check Bonded Devices Database

Central Role Device

```
at+bndl
capacity: 16, rolling: 1, persistent: 0
0 01C7771F7CC04F 001D0000
OK
```

Check Bonded Device Database

1 Rolling Device
Central BTAddr listed

Peripheral Role Device

```
at+bndl
capacity: 16, rolling: 1, persistent: 0
0 01C5D5833F7C96 001D0000
OK
```

Check Bonded Device Database

1 Rolling Device
Peripheral BTAddr listed

9.6 Verify vSP Connections meet Encryption Requirements Setting by S Reg 102 (Optional)

Disconnect the devices by issuing AT+LDSC [Hdlx] command from either device:

- AT+LDSC [Hdlx] // Disconnect Devices

Now that the devices have been paired and bonded with MITM protection all subsequent vSP connections will use the keys stored in the Bonded Device Database to encrypt future connections. To verify send the ATD [Peripheral-BTAddr] command to connect in vSP Bridge Mode.

Peripheral Role Device:

- ATZ // Soft Reset to start vSP Adverts again (required)

Central Role Device:

- ATD [Peripheral-BTAddr] // Connect in vSP Bridge Mode

Peripheral Role Device

```
atz
OK
RING 01C5D5833F7C96, T
ENCRYPT
CONNECT 0, 01C5D5833F7C96, 15000, 6000000, 0
Hello from Central
Hello from Peripheral
```

Soft Reset to start vSP Adverts

Connection uses Stored Keys to Encrypt

Data can now be passed over vSP Bridge

Central Role Device

```
atd 01C7771F7CC04F
ENCRYPT
CONNECT 0, 01C7771F7CC04F, 15000, 6000000, 0
Hello from Central
Hello from Peripheral
```

Connect

Connection uses Stored Keys to Encrypt

Data can now be passed over vSP Bridge

10 CHECKING BONDED DEVICE DATABASE OPTIONS

There are a few commands which can be entered to check the status of bonded devices:

- `ATI 2009` // Returns the # of devices in bonded device database
- `AT+BNDT [BTADDR-Peripheral]` // Checks if specific BTADDR is listed in bonded device database
- `AT+BNDL` // Lists ALL devices in the bonded device database

Note: See sections 3.3.14 and 3.3.15 of [AT Interface User Guide](#) for explanations of these command responses.

```
Central Role Device

OK
ati 2009
1
OK
at+bndt 01C7771F7CC04F
1, 1, 01C7771F7CC04F
OK

OK
at+bndl

capacity: 16, rolling: 1, persistent: 0
0 01C7771F7CC04F 001D0000
OK
```

```
Peripheral Role Device

OK
ati 2009
1
OK
at+bndt 01C5D5833F7C96
1, 1, 01C5D5833F7C96
OK

OK
at+bndl

capacity: 16, rolling: 1, persistent: 0
0 01C5D5833F7C96 001D0000
OK
```

Note:: If the bonded device is removed from the Bonded Device Database from either the Central or Peripheral device, it must also be removed from the other device, or the devices will not be able to connect. Once both sides have been deleted their keys from the database, a new connection and pairing can be completed.

11 REVISION HISTORY

Version	Date	Notes	Contributors	Approver
1.0	9 Jan 2023	Initial Release	Rikki Horrigan	Jonathan Kaye